

For product reference prefix : HAL

Intastop Ltd can take no responsibility for incorrect operation of Hinges that are not fitted as per directed in these instructions

1. Position the door leaf of the hinge on the door.
The raised lip on the hinge leaf is to be rebated into the door to ensure minimal ligature risk.
Ensure the door leaf alignment is seated along the full length of the door edge and mark where the door is to be rebated, also ensure the top edge of the door leaf is flush with the top edge of the door and that the anti ligature tip is at the door head
3. Mark and drill for 12nr. 1 ½" x 10 csk tamper proof screws. Drill 3mm-3.5mm pilot hole **but do not install**
5. Screw the door leaf portion of the hinge to the door
7. Close door and check for proper swing & clearance. Adjust if required
2. If existing gaps are not sufficient to take the frame leaf of the hinge, plane the lipping on the hanging stile as necessary
4. With the hinge leaves open position the hinge against frame jamb. **Ensure the leaf alignment flange is rebated into the face of the frame as before to minimise ligature risk.** Allow 3mm maximum gap between head of the frame & top of the hinge for door clearance. Mark and drill the top two holes for 10csk tamper proof screws, drill 3mm-3.5mm pilot hole **but do not install**
6. Position door at 90 to the frame and install the top two screws in the frame leaf
8. Mark and drill remaining holes, drill 3mm-3.5mm pilot holes for 10csk Phillips head screws and attach to frame

FIXING INSTRUCTION