

For product reference: Intumescent / Brushseals / Neoprene Seals

Intastop Ltd can take no responsibility for incorrect operation of Fire/Smoke Seals that are not fitted as per directed in these instructions.

Intumescent Seal

1. The intumescent is 10mm wide by 2mm deep.
2. Measure the substrate for the length of the product required.
3. Cut the intumescent to length with a Stanley Knife.
4. Router a channel in the substrate ready to take the intumescent, a chisel may need to be used for the top and bottom of door frames.
5. Remove backing from self adhesive tape and press into place.
6. Intastop intumescent can be may be decorated with a wide range of conventional finishes without impairing its performance (please check with our technical dept.)

Brushseals

1. The Brushseal is 9mm wide by 3mm deep.
2. Measure the substrate for the length of the product required.
3. Cut the Brushseal to length with a Stanley Knife/hacksaw.
4. Router a channel in the substrate ready to take the Brushseal, a chisel may need to be used for the top and bottom of door frames.
5. Remove backing from self adhesive tape and press into place.

Neoprene Seals

1. The Neoprene Seal is 10mm wide by 3mm deep.
2. Measure the substrate for the length of the product required.
3. Cut the Neoprene Seal to length with a Stanley Knife/hacksaw.
4. Router a channel in the substrate ready to take the Neoprene Seal, a chisel may need to be used for the top and bottom of door frames.
5. Remove backing from self adhesive tape and press into place.

NOTE

Recommendations on the amount of Intumescent and or Seals necessary for applications cannot be given here as this will vary according to gap sizes, the nature of bonding materials and the period of fire resistance required. Intastops Technical Dept. will be happy to offer advice on specific applications upon request.