

GENERAL INFORMATION:

- The sheet material should be stored flat and protected from damage for a period of 24 hours at ambient temperature before use.
- If the sheet is to be used where there is a likelihood of extremes in changes of temperature, please contact our technical representative.
- when using adhesive to fix this product please refer to current C.O.S.H.H. information and data sheets which are provided with the product (copies available on request).
- The sheet may be cut to size and shaped at works or on site, using a fine toothed saw. All sharp edges should be removed by means of fine file or suitable abrasive sheet.

ADHESIVE INSTALLATION PROCEDURE:

1. Ensure all Surfaces are free from dirt, dust and grease.
2. Measure areas where sheet is to be installed and cut panels to suit (note joints are best made on a grout line).
3. Apply gap filling Contact adhesive to the back of the sheet and to the wall, spread and affix sheet.
4. Consolidate by applying heavy pressure over the entire surface by means of a heavy roller or clamping.
5. Allow 24 hours for adhesive to set
6. When Jointing Sheets do so on a grout line - leave a gap to match the width of the grout line between the 2 sheets.
7. Mix the two part gel coat and apply to the joint – wipe away any excess and leave to harden for 24 hours.

Note:

Refer to Adhesive Data Sheet for C.O.S.H.H. requirements, these are supplied upon request.

FIXING INSTRUCTION